






RSZ70



A 8x32 x27	B x23	C x23	Z x23	N 3x20 x8	NA 4x13 x9	H 6,3x13 x8	P x4
TA x1	TB x1	ZB x12	W x4	X x10	YA M4x22 x1	O x1	R x4



03-12-2018

- | | |
|---|-------------------------------------|
| (D) Montageanleitung | (GB) Assembly Instructions |
| (FR) Notice de montage | (IT) Istruzioni di montaggio |
| (NL) Handleiding voor de montage | (PL) Instrukcja montażu |
| (CZ) Montážní návod | (SK) Návod na montáž |
| (HU) Szerelési útmutató | (RO) Instrucțiuni de montaj |
| (TR) Montaj talimatı | (RU) ИНСТРУКЦИЯ ПО МОНТАЖУ |








1,5 - 2

1







2









7



9






8



10

11



12

